

2321-0029
SPORTSHIELD 9" HDLT. MOUNTING KIT
2005 SUZUKI BOULEVARD C90

TOOLS REQUIRED: 3/16" T-Handle Allen Wrench
3/16" pocket size Allen Wrench
4mm Allen Wrench
5mm Allen Wrench
6mm Allen Wrench
Phillips Head Screwdriver
13mm Socket on a small 1/4" Drive Ratchet

Step 1: Cover the Front Fender and Gas Tank with a towel to protect the finish.

Step 2: Remove the turn signal bar assembly. To access the top bolt you must remove the headlamp from the housing. Remove the two Phillips head screws, one on each side of the headlamp and carefully lift up from the bottom while pulling forward. Note the small locking tab on top. Unplug the three wire connector from the headlamp and set the headlamp aside in a safe place. Using a 4mm Allen wrench (provided) remove the top turn signal bar bolt through the hole in the bottom of the headlamp housing. Remove the two bolts in the bottom of the turn signal bar using a 5mm Allen wrench (provided) and carefully set the turn signal bar on the towel covered fender with the turn signal wiring still attached.

Note: Bend the tabs inside the headlamp that hold the wiring harness and feed the turn signal wires out to get enough slack to lower the turn signal bar to the towel covered fender. During reassembly be sure to pull the wires back into the headlamp and bend the tabs back in place to allow the headlamp to be easily inserted into the housing.

Step 3: Now install your new Memphis Shades mounting brackets one at a time. First loosen the two bolts that hold the rear upper bracket to the front bracket approximately one half turn.(this will help with alignment during assembly)

Locate the two threaded 8mm holes (**not being used**) in the underside of the upper triple tree (one on each side) and install the bracket assembly using the (shorter) 8mm X 12mm SS Hex head bolt and 8mm SS flat washer(provided in the bag). In the lower bracket hole install the (longer) 8mm socket head cap screw using the 6mm Allen wrench (provided) into the threaded hole in the front of the lower triple tree.

Tighten the top bracket to triple tree bolt first using a 13mm socket on a small 1/4" drive ratchet, then tighten the bottom bracket to triple tree bolt using a 6mm Allen wrench (provided). Lastly tighten the two center bolts using the 3/16" T-handle Allen wrench (provided). The upper bolt and center bolts are easily accessed from the back side of the forks after turning the front end all the way to one side. Repeat this process for the other side and reinstall the turn signal bar and headlamp.

Step 4: Turn front end full right and full left to make sure cables or wiring do not bind or hang on anything.

Step 5: Install the mounting plates on the windshield using the bolts that are pre-assembled on the mounting plates.

The santoprene grommets should be inserted through the holes in the windshield so that the flat round part of the grommet lies flat on each side of the plastic.

Note: The Tabs point in towards the center of the windshield if installed correctly.

Step 6: Install the windshield (with mounting plates now installed) onto the bracket and adjust the height and angle and tighten the windshield hardware.

WARNING: This is a Quick Change kit. ALWAYS tighten down all mounting bolts after removing or installing the windshield!

Care and Cleaning Instructions

To clean your windshield, use only warm water and a mild non-abrasive, dishwashing liquid. Use a soft cloth, such as a T-shirt or flannel cloth. To protect your windshield, please use Meguiar's or Novus to remove minor scratches. Use a polish which is specially designed for plastic windshields; glass cleansing agents will cause severe damage to your windshield and will void your warranty.

Never use any glass products, petroleum based chemicals, or cleaning agents with ammonia, bleach or any harsh chemicals. This includes Rain-X, brake fluid, acetone, and gasoline.

2321-0029
SPORTSHIELD 9" HDLT. MOUNTING KIT
2005 SUZUKI BOULEVARD C90

PART #	DESCRIPTION	QTY.
M8805	MOUNTING INSTRUCTIONS/PART LIST	1
M1077	LEFT MOUNTING PLATE	1
M1078	RIGHT MOUNTING PLATE	1
M505	BUTTON NUT	4
M302	1/4" - 20 X 1/2" SOCKET HEAD CAP SCREW	4
M543	SANTOPRENE GROMMET	4
M504	SOCKET SHOULDER WASHER	4

**Memphis Shades warrants all product components, metal and plastic,
against defects in materials and workmanship for 24 months.**

FOR PARTS AND WARRANTY HELP, CONTACT:

MEMPHIS SHADES

P.O. Box 429

Rossville, TN 38066

(901) 853-0293

Visit us on the web at www.memphisshades.com or

you can also reach us at

customerservice@memphisshades.com